

FIAT 500 Steering Column Switch
 LHD (normal) to RHD Configuration Conversion

ROTATION ANGLE : 154°

- A→A' : Headlight & Blinker Levers
- B_{1, 2, 3}→B'→B'' : Fixing Screw and Fitting Keys
- (B) : Keyseat for Keys B (no rotation)
- C : Outer Cover Fixing Key (no rotation)
- (C)→(C')→(C'') : Outer Cover Fixing Keyseat

